## Chlorination

## How it works?

Chlorine kills bacteria and viruses through a simple chemical reaction. The chlorine solution breaks down into different chemicals, including hypochlorous acid (HOCI) and hypoclorite ion (OCI<sup>-</sup>). Both of these chemicals kill microorganisms by destroying the enzymes and structures inside the cell. When enzymes come in contact with chlorine, hydrogen atoms in the enzymes are replaced by chlorine atoms. This causes the entire molecule to change shape or fall apart. When enzymes don't function properly, the cell or bacterium dies.


HOCI works faster because it is electrically neutral and is able to enter the negatively charged cell wall, while OCI<sup>-</sup> is electrically negative and is therefore repelled by the cell wall (like two negative magnets) and can only act on the surface. HOCI can kill microorganisms in several seconds, while OCI<sup>-</sup> may take up to 30 minutes. The pH of the water determines how much of the chlorine solution breaks into HOCI and how much breaks into OCI<sup>-</sup>. When the pH is low, more Hydrogen (H<sup>+</sup>) atoms exist in the water and OCI<sup>-</sup> can easily be converted to HOCI and the disinfection process is more effective. Ideal pH for chlorination is between 5.5 and 7.5. At a pH of 6, the ratio is 80% HOCI and 20% OCI<sup>-</sup>, at a pH of 7.5 equal amounts exist of each and at a pH of 8, the ratio is 20% HOCI and 80% OCI<sup>-</sup>.

## In Practice

Chlorine gas (Cl<sub>2</sub>) is the lease expensive form of chlorine but is the most dangerous since it is stored in pressurized tanks. Calcium hypochlorite can also be used, but is more expensive. Sodium hypochlorite (NaOCI) is found in household bleach and is the most common form of chlorine used for small-scale/household-level treatment. (be aware that the addition of NaOCI increases the pH.)

 $\begin{array}{l} \text{NaOCI} \rightarrow \text{Na}^{+} + \text{OCI}^{-} \\ \text{H}^{+} + \text{OCI}^{-} \rightarrow \text{HOCI} \end{array}$ 





## Procedure

The US EPA recommends the following chlorination procedure:

- 1. If cloudy, filter the water through a cloth or allow it to settle.
- 2. Add two drops per liter of unscented bleach (the bleach should contain 4-6% chlorine).
- 3. Stir and wait 30 minutes.

Time to Treat: about 35 minutes (5 minute preparation; 30 minute wait) regardless of quantity

Advantages	Disadvantages
Common (information available)	Can be dangerous if not used properly
Available in most countries	Taste and odor issues can arise
Very effective when used properly	Disinfection byproducts (DBPs) are created
Provides residual disinfection	Not effective against Cryptosporidium or Giardia
	Organic matter and particles can interfere
	Skepticism due to unchanged appearance